

## **Shower Base installation instructions**

- 1. Our shower bases are made to fit against the wall studs. Make rough opening ½” larger than the shower base dimensions. If waterproof board is already in place it must be cut for the base to fit properly. DO NOT drill holes in the flange and attach base to wall studs.**
- 2. Place shower base in desired location and mark hole in floor to cut drain. Hint-cut drain hole a little larger to easily accept drain when sitting into place. Check base to make sure it is level. If you need to level place shims under base to achieve this. Tack shims to the floor, remove the base and attach drain assembly into bottom of base. Use mildew resistant 100% silicone to seal drain. Place enough mortar mix on the floor to level the base. Put shower base back into place and move it around until it sits on your shims. Shower base must be supported evenly and not move when you step in it. When mortar dries remove the shims.**
- 3. Install waterproof board so it sits on top of the flange on the showerbase.**
- 4. When installing wall panels or tile be sure to have them sit on the base floor.**
- 5. Base may be kept clean by using a mild detergent or shower spray. Avoid abrasive cleaners.**
- 6. Enjoy your new cast polymer shower base! With proper installation and care your base will provide you with many years of service.**

**AL-CO PRODUCTS INC.  
485 SECOND STREET PO BOX 74  
LATTY, OHIO 45855  
PHONE-1-800-686-2489  
FAX -419-399-4702**